rutpen limited

SOCOTEC | ISO 9001 | ISO 18001 | OHSAS 18001 | U.K.A.S. | OHSAS 18001 |

MEMBURY AIRFIELD LAMBOURN, BERKS, RG17 7TJ

Telephone: (01488) 71926

Facsimile: (01488) 71947 Email: mail@rutpen.co.uk

Beta Superior No 1 Case Hardening Compound

Recommended Directions for Use on Mild Steel

- 1. Heat the component uniformly from mid to bright cherry red in colour (720 750C)
- 2. Dip/roll the component in the compound and leave for 1 2 minutes.
- 3. Remove from the compound and gently brush away the excess build-up of the compound.
- 4. Leaving 1 2 mil thickness of residue on the surface re-heat the component until the compound on the surface starts to darken and liquefy.

Steps1,2,3 and 4 can be repeated 2 - 3 times until the desired depth of hardening has been achieved. Following the final heat process the component should be quenched in clean cold water using a scrubbing action to maximise cooling.









Directions for Use on Tool Steel

Heat the component as above and dip/roll in the compound until the right tempering heat is reached. Re-heat and repeat the process until the desired depth of hardening is achieved then quench in clean cold water or oil. This will produce the ultimate in hardness and also prevent cracking.

Directions for Deeper Cases on Mild Steel

Cover the component in the compound in an open shallow receptacle and heat to 720 - 750C for 15 - 60 minutes depending on the depth of hardness required. Use dry tongs to remove from the molten compound and quench only in clean water.

We would always recommend running through the process with an initial test piece prior to use.

This process will evolve toxic fumes, you must consult the SDS and perform your own risk assessment.

No conditions or warranty is to be implied by the foregoing information.